


The logo for the E3 series features a large, stylized red 'E3' with a motion blur effect. Below it, the word 'series' is written in a bold, black, sans-serif font.

series

Bugfixes
2016-17.13



Technical Inquiries

Please ask the responsible contact person in our support department.

E-mail: e3-support@zuken.com

Note:

Zuken is not responsible for any errors, which may appear in this documentation. Liability, due to direct and indirect losses resulting from the delivery or use of this documentation, is excluded to the extent permitted by law. This documentation contains copyrighted information. All rights, especially those pertaining to the duplication and distribution as well as the translation, are reserved. This documentation, whether wholly or in part, may not be reproduced in any form (photocopy, microfilm, etc.), or processed, duplicated or distributed using an electronic system without Zuken's prior written consent.

Contact

Zuken E3 GmbH
Laemmerweg 55
D-89079 Ulm/Einsingen

Phone : +49 7305 9309-0
Fax: +49 7305 9309-99
Web: <http://www.zuken.com>
E-mail: e3-info@zuken.com

Bugfixes

INFORMATION	
	<p>When opening a project with the new version (2016-17.13), projects of the directly previous version (2016-17.12)</p> <p>are converted and can no longer be opened with the previous version <input type="checkbox"/> Single-User <input checked="" type="checkbox"/> Multi-User</p> <p>are not converted and can still be opened with the previous version <input checked="" type="checkbox"/> Single-User <input type="checkbox"/> Multi-User</p> <p>COM Registration <input checked="" type="checkbox"/> the COM library has been changed and should be registered again (start the program as ADMIN using „E3.series.exe /register“)</p>

The bug fixes are sorted and listed by designer number(s). This enables you, for example, to easily search for bugs reported to our support office.

Designer-15899	Coordinate input ('P) useless when moving objects
Designer-21245	Shield symbol partly hidden although other levels defined for the shield in DBE
Designer-21614	Dimensions can be added to objects hidden by levels
Designer-21930	Texts from language database are not translated for HLA/LOC in tree
Designer-23866	Wrong pin assignment with feed-through connector's mating connector
Designer-23950	When defining prefix only, sheet is assigned an empty Product in "Sheet Properties"; Function and Location are correctly entered as <no entry>
Designer-24281	No alternative grid with 'Place as Graphic' from within Database window
Designer-24979	Text contents of text type "Item designation" (#1062) not displayed after importing subcircuit
Designer-25074	When jumping to tree, focus remains on sheet instead of symbol in tree
Designer-25576	When opening a read-only file with E3.Viewer, the warning 'Project has been opened in READ ONLY mode, you can't save any changes to the existing project!' appears
Designer-26073	Differing jump behavior between E3 and PDF when using text type "Connection Target Format 1" (#1085) on a signal cross-reference
Designer-26129	Text type "Device designation" (#32) on sheet is not displayed in

	the Sheet Properties
Designer-26324	The command 'Place at original position' doesn't work for attribute text template symbols (it is always placed on the current cursor position)
Designer-27226	"Update in project" of a database assembly removes single components from assembly (reason: component version)
Designer-27679	Behavior of terminals with options/variants assignment at sorting/numbering
Designer-28211	Command 'Unconnect Delete Signal' doesn't delete the signal on signal cross-reference symbols
Designer-28405	MUADMIN TOOL's "Sheet permissions" tab doesn't show projects in subfolders
Designer-28682	Wrong measurement unit setting within DBE leads to recalculation of units for outer diameter and cross section when editing wire groups
Designer-28887	When switching the symbol characteristic, user-defined signals are swapped without any query
Designer-29049	The COM method 'Job.UpdateComponent' returns 1, even if the component doesn't exist in the database
Designer-29050	Depending on the monitor resolution tooltip is cut
Designer-29089	Single conductors of a dynamic cable can't be deleted when this cable represents the default variant within project
Designer-29092	When an attribute is used as display name within the tree structure, the list of connector pin terminals displays the attribute value from the first component version instead of the current version
Designer-29123	When the symbol type is changed during the symbol definition, a 'Grouped symbol for bundles' can be saved with a changeable oval
Designer-29149	Placing an attribute text template symbol directly after changing cable type generates a new device and causes the following message 'E - CCID:001225: check_attribute_templates(): 'CABLE_ITEM/[xxx]' contains CELL-ITEM 'CELL_ITEM/[xxx]' in the attribute template list with different owner from itself'
Designer-29170	Text type 'Reference to pin number' (#1070) doesn't show all bus pins, only the first one
Designer-29188	No ability to place models - 'W - Digitized point outside current graphics window ignored !'
Designer-29190	Text types "Connection Target device designation" (#1075) and "Connection Target" (#1002) assigned to MIL symbols show own device instead of the device of the connection target
Designer-29201	"Display - Alternative text as component code" setting is reset upon opening a project, if the value currently set is an attribute with owner AOWN_COMP or AOWN_CABTYP as alternative component code
Designer-29211	No display of snap points for dimension when cable ducts or mounting rails directly end on the edge of a mounting plate
Designer-29272	Triggered script causes error message 'E - Error in function hntext\find_celtxt(), ret = 1'
Designer-29283	Refresh of symbols may lead to infinite loop
Designer-29310	Not all connections are created in panel despite activated setting "Route wire jumpers at the end"

Designer-29312	Wire is renamed at import of sub-circuit to an empty project when the setting 'Create unique names' is active
Designer-29313	After deletion of cables/hoses/tubes from database, the attributes remain existing with "conductors" in the DB
Designer-29314	Instead of "Delete Forced", the command "Delete" appears at dynamic assemblies although a view of an assembly element is placed (the assembly is also deleted with "Purge Unused Objects...").
Designer-29319	No ability to select Windows group for E3MUADMIN at MU-Setup
Designer-29345	Variant definition is not accepted on connection line within view
Designer-29346	Component names may not be listed at search within the database tree with an SQLDB
Designer-29351	Wire name is not updated at change of partial signal although it is an element of the wire name
Designer-29365	Elements within overbraids containing variants/options are not deactivated
Designer-29367	COM-Call: "Device.GetValidComponentCodes" doesn't return any items for cables
Designer-29376	No ability to create a new MU project when access to the model DB occurs simultaneously
Designer-29397	Multiuser 2016: Despite the result of trigger "BeforCheckOutSheet", the sheet can be opened and edited by double-clicking
Designer-29398	Components/symbols/models without names can be created with 'F2' ind database tree - stored in dabase may cause problems
Designer-29400	E3.ReportScripts: PLC-Address Management - Column N (Pin Id) is not included in sort
Designer-29422	When moving a model, other models are also moved for no apparent reason
Designer-29427	Editing a signal attribute value via "F2" on attribute text template symbol is not possible with attribute owner "signal" resp. creates net attribute with owners "signal,net"
Designer-29432	Programs do not recognize that they don't run under operating system Windows Server 2008 SP2 correctly - now correct checking
Designer-29433	Fields in Project window's tree view (Sheet tree) are not displayed if schematic type "Electric" is not selected for the tree view
Designer-29508	Some specific projects cannot be opened in E3 version 2015/2016
Designer-29521	The COM function 'Sht.CheckOut()' returns an incorrect value



Americas

North America

Zuken USA Inc.
Westford, MA 01886, USA
Tel: +1 978 692 4900

Asia

Japan

Zuken (World Wide Head Office)
Yokohama, Kanagawa 224-8585, Japan
Tel: +81 45 942 1511

China

CIM-TEAM Software Technology Co., Ltd.
Changning District, Shanghai, China, 200336
Tel: +86-21-52280180

Korea

Zuken Korea Inc.
Seoul 135-283, Korea
Tel: +82 2 5648031

Singapore

Zuken Singapore Pte Ltd.
#22-05 Gateway East, Singapore 189721
Tel: +65 6392 5855

Taiwan

Zuken Taiwan Inc.
Taipei 110, Taiwan
Tel: +886 2 7718 1116



Europe

Germany

Zuken GmbH (European HQ)
D-85399 Hallbergmoos, Germany
Tel: +49 89 7104059 00

Zuken E3 GmbH
D-89079 Ulm, Germany
Tel: +49 7305 9309 0

Zuken E3 GmbH
D-30659 Hannover, Germany
Tel: +49 511 8595 9489

Switzerland

Zuken E3 GmbH
CH-5506 Mägenwil, Switzerland
Tel: +41 56 437 08 90

United Kingdom

Zuken UK Ltd.
Bristol, BS32 4RF, UK
Tel: +44 1454 207 801

France

Zuken S.A.
#91974 Les Ulis Cédex, France
Tel: +33 1 69 29 48 00

Italy

Zuken S.r.l.
20090 Milanofiori Assago, Milan, Italy
Tel: +39 02 575 921

Netherlands

Zuken GmbH
NL-6075 HA Herkenbosch, The Netherlands
Tel: +31 475 520 998